

YORK[®]

SECTION 1

OPEN TURBOPAK CENTRIFUGAL LIQUID CHILLING UNITS

RENEWAL PARTS

Supersedes: Nothing

1073 Form 160.58-RP (Sect. 1)

MODELS OT A1 A3 THRU OT K3 E3(STYLE A)
90 THRU 650 TONS

TURBOPAK PARTS




TABLE OF CONTENTS

OT TURBOPAK UNIT PARTS	160.58-RP (Section 1)
COMPRESSORS LTD53 THRU LTD126	160.58-RP (Section 2)
COOLERS AND CONDENSERS	160.43-RP (Section 3)
TURBOGUARD PURGE UNIT	160.43-RP (Section 4)
ELECTRONIC AND PNEUMATIC CONTROL	160.43-RP (Section 5)

OT TURBOPAK UNIT PARTS

OT A1 THRU OT K3





FIG. 1 — OPEN TURBOPAK — FRONT VIEW





FIG. 2 — OPEN TURBOPAK — REAR VIEW


TABLE 1 — BASIC UNIT PARTS

ITEM	PART DESCRIPTION	QUAN.	PART NUMBER			
			OT A1 THRU A5	OT B1 THRU B3 C1 & C2	OT D1, D2, E1, F1, G1 & G2	OT H1 THRU HT H4 OT J1 THRU HT J3 OT K1 THRU HT K3
1	GASKET, SUCTION CONNECTION	2	028-08778-001	028-08778-002	028-08778-003	028-08778-004
2	GASKET, DISCHARGE	1	070-12343	070-12208	070-10630	070-10633
3	BURSTING, DISC	1	026-09353 ²	026-09353 ²	026-09353 ²	026-09353 ²
4	GASKET, BURSTING DISC	2	070-15845 ²	070-15845 ²	070-15845 ²	070-15845 ²
5	ISOLATOR	7	028-02162	028-02162	028-02162	028-02162
6	SOLENOID VALVE	1	025-16914	025-16914	025-16914	025-16914
7	DEHYDRATOR	1	026-14777-007	026-14777-007	026-14777-007	026-14777-007
8	EDUCTOR, OIL RETURN	1	364-18241	364-18241	364-18241	364-18241
9	MOTOR	1	SEE DATA NAMEPLATE	SEE DATA NAMEPLATE	SEE DATA NAMEPLATE	SEE DATA NAMEPLATE
10	VALVE, SOLENOID	1	025-16988	025-16988	025-16988	025-16988
11	VALVE, CHECK	1	022-03902	022-03902	022-03902	022-03902
12	ISOLATOR	4	028-08972	028-08972	028-08972	028-08972


²Order Bursting Disc Kit 367-35263

ISOLATORS, NEOPRENE


SHELL CODE	PART NO.
A1 THRU G2	028-09254
H1 THRU K3	028-09253



ISOLATION MOUNTING
PAD FOR SHELL CODES
H1 THRU K3




ISOLATION MOUNTING
PAD FOR SHELL CODES
A1 THRU G2




ISOLATION MOUNTING
PAD INSTALLED

FIG. 3 — NEOPRENE ISOLATOR INSTALLATION

OPTIONAL SPRING — ISOLATORS (4 PER UNIT)



FOR MODELS
A1 THRU G2



FOR MODELS
H1 THRU K3





FIG. 4 — SPRING ISOLATORS


SHELL CODE	PART NO. UNIT W/COMPACT WATER BOXES	PART NO. UNIT W/MARINE WATER BOXES
A1, A2, A3, A4, A5	029-11412	029-11412
B1, B2, B3	029-11413	029-11413
C1, C2	029-11413	029-11414
D1, D2	029-11414	029-11414
E1	029-11414	029-11415
F1, G1, G2	029-11415	029-11415
H1, H2, H3, H4	029-13006	029-13006
J1, J2, J3	029-13006	029-11579
K1, K2, K3	029-11579	029-11579

COMPOUNDS

DESCRIPTION	QUAN.	PART NO.
COMPOUND, HEAT CONDUCTIVE (FOR THERMOMETER WELLS)	4 OZ. CAN	013-00898

TOUCH-UP PAINTS – SPRAY CANS

DESCRIPTION	PART NO.
CARRIBEAN BLUE ENAMEL	013-01835
FAWN GRAY ENAMEL (CONTROL CENTER)	013-01836



SUBJECT TO CHANGE WITHOUT NOTICE

PRINTED IN U.S.A.

COL 6M 1073 .15

Form 160.58-RP (Sect.1)

Code: S(J) & R(JM)

S(J) & R(JM) - Int.

YORK DIVISION OF BORG-WARNER CORPORATION
BORG-WARNER

P.O. BOX 1592, YORK, PENNSYLVANIA 17405